



Best Practices in Processing Obsolete Brachytherapy Sources at PNNL

May 30, 2024

Joel Tingey
Anne Farawila
Matthew Fountain
Matthew O'Hara
Benjamin Scheibe
Jamin Trevino



PNNL is operated by Battelle for the U.S. Department of Energy



PNNL Experience Handling ^{226}Ra from Obsolete Brachytherapy Sources

^{226}Ra

FROM OBSOLETE BRACHYTHERAPY SOURCES

Gram quantities of radium at PNNL
Large global inventory




PRODUCTION DEVELOPMENT

100's mCi/batch
Normal needles and tubes
A-typical sources





CHALLENGE


Develop ^{226}Ra recovery process for a wide variety of configurations
Minimize dose to staff
Contamination free product vial



Facility and Processes



Dose, Effluent, and Contamination Challenges



- Dose

- High β dose from progeny
- Approximately 90% activity in-growth in 13 days
- Material degradation from both α and β decay




- Effluents

- ^{222}Rn (gas)
- Based on RPL ^{222}Rn emissions release limit, abatement of ^{222}Rn is not required

- Contamination

- ^{226}Ra contamination can contribute to ^{222}Rn emissions from the facility and build-up of dose in facility ductwork

In-Growth of Progeny



Contamination Control

- Maximize recovery of ^{226}Ra
- Minimize contamination
 - ^{226}Ra
 - Progeny including gaseous ^{222}Rn
- Store ^{226}Ra in closed containers
 - Vent only when being processed
- Secondary containment
 - Opening the brachytherapy sources
 - Separation
 - Evaporation
- Equipment designed to be cleaned with a containment vessel for cleaning solutions and rinses
- Regular housekeeping


^{222}Rn Control and Monitoring

- ^{222}Rn permeates plastics and rubber
 - O-rings and seals
 - Bags
- Stainless steel Swagelok® container is the airtight container for shipping and storage
- Timeliness from evaporation to packaging is important in minimizing ^{222}Rn and its progeny in the product
 - Contamination
 - Dose during handling (< 2 mrem per batch)
- Monitor activity
 - Roughing filter (increased dose has not been observed)
 - Stack



Dose Considerations

- α and β - dose from in-growth of progeny can degrade product container
 - Darkening of the borosilicate glass vial observed at 65 days
 - Cap and rubber liner showed no visual signs of degradation at 65 days
- Digital electronics are shielded to protect against radiation induced degradation



^{226}Ra Packaging

- Product is a dry crystalline solid
- Borosilicate glass vial minimizes contamination of the product from materials of construction
 - For long-term storage metal cap is preferred
 - Metal vial should be considered for long-term storage
- Stainless steel Swagelok[®] container is the airtight container
 - No contamination observed outside the container
 - Likely internally contaminated at receipt
- Type A package shipped as Yellow II or Yellow III
- Modeling for shipping documentation
 - Activity increases during shipment





PNNL Core ^{226}Ra Production Team

- Matt Fountain
- Jamin Trevino
- Anne Farawila
- Ben Scheibe
- Isaac “Shiva” Miller
- Lucas Boron-Brenner
- Matt O’Hara
- Michael Hansen

Acknowledge the financial support of the DOE Isotope Program



**Pacific
Northwest**
NATIONAL LABORATORY

Thank you

